

Turning On Water To A Slide

These instructions apply only to pools built by Swimming Pool Services Inc. in conjunction with manufacturer's instructions for any specified product.

1. Locate valve for slide. It will be at equipment pad, in pipe, after heater outlet, before valve for return lines.
2. Open valve. Some slides have a valve at the slide, usually close to the ground.
3. If you do not have the desired amount of water volume coming down the slide you can throttle down return lines using valve for return lines. Turn the valve to the right or left making sure not to turn off returns completely. Check filter pressure and make sure that it has not risen more than 10 psi.