

Operating an Auto Cover

These instructions apply only to pools built by Swimming Pool Services Inc. in conjunction with manufacturer's instructions for any specified product.

- 1.** Make sure there is no water on the cover before opening. ***You should have received a pump for removing water, along with your cover.
- 2.** Make sure there is no debris or other objects on the cover (i.e. pool toys, branches)
- 3.** Turn key switch to “open” position to open cover. While doing so, you want to watch cover to make sure both sides are moving and are moving at same speed.
- 4.** When the cover lead bar is one foot from the end of the pool, release the key. “Jog” the cover with the key 2 or 3 times or until it reaches the end of the pool.
- 5.** Listen for any “tearing” sounds, and do not open cover too far (meaning do not run cover out of the track and into the cover box.)
- 6.** To close, turn key towards “close” position. Again make sure both sides of cover are moving and at the same speed.
- 7.** When the cover lead bar is one foot from the end of the pool, release the key. “Jog” the cover with the key 2 or 3 times or until it reaches the end of the pool.

*Note: If cover stops moving or does not respond when key is turned, call S.P.S.